

INSTALLATION AND OPERATING INSTRUCTIONS

KBWS WHISPER DRIVE


PULSE WIDTH MODULATED (PWM)

DC Motor Speed Control with Built-In Input Signal Isolation

See Table 1 on page 10 for a list of KBWS
Models covered by this manual

*The information contained
in this manual is intended to be accurate.
However, the manufacturer retains
the right to make changes in design
which may not be included herein.*

**Note: A PLug-In Horsepower Resistor®
must be installed for this product to
operate (supplied separately).**



Hi-Pot
Tested
1500 VAC



**See Safety Warning on Page 5 before
installing and operating this control**

PENTA **KB** POWER™

A COMPLETE LINE OF MOTOR DRIVES

© 2001 KB Electronics, Inc.

Spec Tech Industrial 203 Vest Ave. Valley Park, MO 63088 Phone: 888 SPECTECH
Email: sales@spectechind.com www.spectechind.com

TABLE OF CONTENTS

Section	Page
i. Simplified Operating Instructions	4
ii. Safety Warning	5
I. Introduction	6
II. Plug-In Horsepower Resistor®	11
III. Wiring Instructions	12
IV. Setting Selectable Jumper (On Dual Voltage Models)	15
V. Mounting Instructions	15
VI. Recommended High Voltage Dielectric Withstand Testing (Hi-Pot Testing)	16
VII. Operation	18
VIII. AC Line Fusing	18
IX. Trimpot Adjustments	18
X. Diagnostic LEDs	22
XI. Optional Accessories	23
XII. Limited Warranty	24

Tables


1. Electrical Ratings	10
2. General Performance Specifications	11
3. Plug-In Horsepower Resistor® Selection	12
4. Recommended AC Line Fuse	18

Figures	Pages
1. Control Layout	8
2A. Mechanical Specifications	9
2B. Mechanical Specifications	10
3. Plug-In Horsepower Resistor®	11
4. Power Connections	13
5. Main Speed Potentiometer Connection	13
6. Voltage Following Connection	14
7. Inhibit Connection	14
8. Enable Circuit Connection	14
9. Motor Voltage Selection (J1) (Dual Voltage Models)	15
10. Hi-Pot Test Setup	17
11. Maximum Speed Trimpot (MAX) Range	19
12. Minimum Speed Trimpot (MIN) Range	19
13. Acceleration Trimpot (ACC) Range	20
14. Deceleration Trimpot (DEC) Range	20
15. Current Limit Trimpot (CL) Range	20
16. IR Compensation Trimpot (IR) Range	21

i. SIMPLIFIED OPERATING INSTRUCTIONS

IMPORTANT – You must read these simplified operating instructions before proceeding. These instructions are to be used as a reference only and are not intended to replace the detailed instructions provided herein. You must read the Safety Warning on page 5 before proceeding. See Application Note, Section VII, on page 18.

- A. Power Connection** – Connect the AC line to L1 and L2 terminals, as shown in Figure 4, on page 13 and as described in Section IIIA, on page 13.
- B. Permanent Magnet (PM) Motor Connection (Two Wire Type)** – Connect the motor armature to terminals A+ and A- as shown in Figure 4, on page 13 and as described in Section IIIB, on page 13. On dual voltage models, be sure that Jumper J1 is set to the corresponding motor voltage position, as described in Section IV, on page 15.
- C. Plug-In Horsepower Resistor®** – Install the proper Plug-In Horsepower Resistor® (supplied separately) according to motor current and horsepower. See Table 3, on page 12.
- D. Trimpot Settings** – All trimpots have been factory set, as shown in Figure 1, on page 8. Trimpots may be readjusted, as described in Section IX, on page 18.
- E. Diagnostic LEDs** – After power has been applied, observe the LEDs to verify proper control function, as described in Section X, on page 22.

 This product complies with all CE directives pertinent at the time of manufacture. Contact the Sales Department for detailed installation and Declaration of Conformity. Installation of a CE approved RFI filter (KBRF-300 [P/N 9484] or equivalent) is required. Additional shielded motor cable and/or AC line cables may also be required.

ii.   **SAFETY WARNING! Please read carefully**

This product should be installed and serviced by a qualified technician, electrician, or electrical maintenance person familiar with its operation and the hazards involved. Proper installation, which includes wiring, mounting in proper enclosure, fusing or other over current protection, and grounding can reduce the chance of electrical shocks, fires, or explosion in this product or products used with this product, such as electric motors, switches, coils, solenoids, and/or relays. Eye protection must be worn and insulated adjustment tools must be used when working with control under power. This product is constructed of materials (plastics, metals, carbon, silicon, etc.) which may be a potential hazard. Proper shielding, grounding and filtering of this product can reduce the emission of radio frequency interference (RFI) which may adversely affect sensitive electronic equipment. If further information is required on this product, contact the Sales Department.

This control contains electronic Start/Stop circuits that can be used to start and stop the control. However these circuits are never to be used as safety disconnects since they are not fail-safe. Use only the AC line for this purpose.

Be sure to follow all instructions carefully. Fire and/or electrocution can result due to improper use of this product.

This control does not contain protection circuitry to prevent full speed runaway in the event of main power transistor failure. However, an optional Product Safety Module (PSM) (P/N 9995) can be installed to prevent full speed runaway. If a PSM is not used, the installer of this product should take proper precautions to include other means, such as mechanical disconnects, warning notices, etc., to protect the operator of the machine involved.

It is the responsibility of the equipment manufacturer and individual installer to supply this Safety Warning to the ultimate end user of this product. (SW effective 1/2001).

I. INTRODUCTION

Thank you for purchasing the KBWS. KB Electronics, Inc. is committed to providing total customer satisfaction by producing quality products that are easy to install and operate. The KBWS is manufactured with surface mount components incorporating advanced circuitry and technology.

The KBWS PWM (pulse width modulated) controls are designed to operate PWM and SCR rated Permanent Magnet motors ranging from 1/50 HP to 1½ HP. They operate at a switching frequency greater than 16 kHz to provide high motor efficiency and quiet operation. Another advantage of PWM is higher output voltage (up to 130 Volts DC for 115 Volt AC line and 220 Volts DC for 208/230 Volt AC line) which provides increased motor speed.

The KBWS contains pulse-by-pulse current sensing, which provides short circuit protection and prevents control damage due to commutator arcing. Permanent magnet motor demagnetization is completely eliminated because current peaks are reduced to safe levels. The controls contain an AC inrush current limiter (ICL) which reduces the AC line surge current during cycling of the AC line.

Standard features of the KBWS include diagnostic LEDs for Power On and Current Limit indication. Other features include adjustable trimpots for maximum speed, minimum speed, acceleration, deceleration, current limit and IR compensation. Also provided is a connector for an Inhibit Switch and quick-connect terminals for AC line, motor armature and Main Speed Potentiometer. The KBWS can be operated from a two wire start/stop circuit or can be started from the AC line.

Due to its user-friendly design, the KBWS can be easily tailored to specific applications. See Table 1 on page 10, for electrical ratings. The Plug-In Horsepower Resistor® matches the motor characteristics to the control without having to recalibrate the Current Limit (CL) and IR Compensation (IR) trimpots. Therefore, for most applications, no adjustments are necessary.

The KBWS contains built-in isolation for all signal inputs. This includes input signal voltage, Main Speed Potentiometer terminals, Inhibit Circuit and +5VDC power supply. The dual voltage models contain a jumper to select motor voltage and special circuitry which automatically accepts AC Line input voltages of 115 or 208/230 Volts AC without having to make a jumper selection. See Application Note, Section VII, on page 18.

Optional accessories for the KBWS include a DIN Rail Mounting Kit, a Product Safety Module (PSM) and an AC Line Fuse Kit. See Section XI, on page 23.

STANDARD FEATURES

- A. Plug-In Horsepower Resistor®** – Automatically calibrates IR Compensation and Current Limit.
- B. Diagnostic LEDs** – Power On (PWR ON) and Current Limit (CL).
- C. Short Circuit Protection** – Protects the control from a short circuit at the motor.
- D. Isolated Signal Input Circuit** – Eliminates the need for an external signal isolator.
- E. Protection Features** – Undervoltage protection. MOV input transient protection. AC Inrush current limit protection.
- F. Inhibit Circuit** – Provides electronic coast-to-stop.
- G. Auto AC Line Select** – Control automatically adjusts for 115 or 208/230 Volt AC line input (dual voltage models).
- H. Motor Voltage Selection** – Allows motor voltage to be set to 90/130 or 180 Volts DC (dual voltage models).

FIGURE 1 – CONTROL LAYOUT

(Illustrates Factory Setting of Jumpers and Approximate Trimpot Settings)




FIGURE 2A – MECHANICAL SPECIFICATIONS (Inches / [mm])




FIGURE 2B – MECHANICAL SPECIFICATIONS (Inches / [mm])




TABLE 1 – ELECTRICAL RATING

Model		AC Line Input Voltage ($\pm 10\%$, 50/60 Hz) (Single Phase Volts AC)	Motor Voltage (Volts DC)	Maximum AC Line Current (Amps AC)	Maximum Load Current (Amps DC)	Maximum Horsepower Rating HP, (kW)	
						SCR Rated Motors	PWM Rated Motors
KBWS-12	9490	115	0 - 90, 130	4.0	2.5	1/4, (0.18)	1/3, (0.25)
KBWS-15	9491	115	0 - 90, 130	8.0	5.0	1/2, (0.37)	3/4, (0.5)
KBWS-22D*	9492	115	0 - 90, 130	4.0	2.5	1/4, (0.18)	1/3, (0.25)
		208/230	0 - 180, 220	4.0	2.5	1/2, (0.37)	3/4, (0.5)
		208/230	0 - 90, 130	4.0	2.5	1/4, (0.18)	1/3, (0.25)
KBWS-25D*	9493	115	0 - 90, 130	8.0	5.0	1/2, (0.37)	3/4, (0.5)
		208/230	0 - 180, 220	8.0	5.0	1, (0.75)	1½, (1)
		208/230	0 - 90, 130	8.0	5.0	1/2, (0.37)	3/4, (0.5)

* See Sections 1G and 1H on page 7.


TABLE 2 – GENERAL PERFORMANCE SPECIFICATIONS

Parameter	Specification	Factory Setting
AC Line Voltage Regulation (% Base Speed)	0.5	—
Armature Voltage Range at 115 Volt AC Line Input (Volts DC)	0 – 130	90
Armature Voltage Range at 208/230 Volt AC Line Input (Volts DC)	0 – 130, 0 – 220	180
Maximum Load Capacity (% for 2 Minutes)	150	—
Switching Frequency at Motor (kHz)	>16	—
Signal Following Input Voltage Range (Volts DC)	0 – 5	—
Maximum Speed Trimspot (MAX) Range (% Base Speed)	70 – 100	100
Minimum Speed Trimspot (MIN) Range (% Base Speed)	0 – 30	0
Acceleration Trimspot (ACC) Range (Seconds)	0.2 – 10	1
Deceleration Trimspot (DEC) Range (Seconds)	0.2 – 10	1
Current Limit Trimspot (CL) Range (% Full Load)	0 – 200	150
IR Compensation Trimspot (IR) Range at 90/130 Volts DC Output (Volts DC)	0 – 10	—
IR Compensation Trimspot (IR) Range at 180/220 Volts DC Output (Volts DC)	0 – 20	10
Speed Regulation (50:1 Speed Range) (% Base Speed)	1	—
Speed Range (Ratio)	50:1	—
Operating Temperature Range (°C)	0 – 45	—

II. PLUG-IN HORSEPOWER RESISTOR®

A Plug-In Horsepower Resistor® (PHR) must be installed for the KBWS to operate. Select a Plug-In Horsepower Resistor® to match the motor characteristics to the control. See Figure 3 and Table 3 on page 12. The PHR plugs into the two female terminals that are provided on the KBWS. Plug-In Horsepower Resistors® are supplied separately by your distributor.

FIGURE 3 – PLUG-IN HORSEPOWER RESISTOR®





Note: Disconnect main power when installing or changing the Plug-In Horsepower Resistor®.

TABLE 3 – PLUG-IN HORSEPOWER RESISTOR® SELECTION

Motor Current (Amps DC)	SCR Rated Motor Horsepower Ranges (HP)		PWM Rated Motor Horsepower Ranges (HP)		Plug-In Horsepower Resistor®		CL Setting (Amps DC)
	90 Volt DC	180 Volt DC	130 Volt DC	200 Volt DC	Ω	Part No.	
3.3 – 5.0	1/3 – 1/2	3/4 – 1	1/2 – 3/4	1 – 1½	0.1	9838	7.5
2.5	1/4	1/2	1/3	3/4	0.18	9837	3.8
1.3 – 2.0	1/8 – 1/6	1/4 – 1/3	1/6 – 1/4	1/3 – 1/2	0.25	9836	3.0
0.7 – 1.0	1/15 – 1/10	1/6 – 1/5	1/12 – 1/8	1/6 – 1/4	0.51	9834	1.5
0.4 – 0.6	1/30 – 1/20	1/15 – 1/10	1/20 – 1/15	1/8 – 1/6	1	9833	0.9
0.1 – 0.3	1/100 – 1/50	1/50 – 1/25	1/50 – 1/30	1/25 – 1/20	2.0	9949	0.5

Notes: 1) 1 HP = 0.75 kW. 2) The HP marking on the Plug-In Horsepower Resistor® does not apply to PWM controls.

III. WIRING INSTRUCTIONS



Warning! Read Safety Warning, on page 5 before using this control. Disconnect the AC line before wiring.

Note: To avoid erratic operation, do not bundle AC line and motor wires with wires from signal following, Start/Stop Switch, Enable, or any other signal wires. Use shielded cables on all signal wiring over 12" (30cm). Shield should be earth grounded on the control side only. Wire the control in accordance with the National Electrical Code requirements and other codes that may apply to your area. See Figure 4 on page 13.

Be sure to properly fuse each conductor that is not at ground potential. Do not fuse neutral or grounded conductors. See Section VIII, on page 18. A separate AC line switch or contactor must be wired as a disconnect so that each ungrounded conductor is opened. See Application Note, Section VII, on page 18.



Warning! Do not wire switches or relays in series with the armature. Armature switching can cause catastrophic failure of motor and/or control.

A. AC Line Connection – Wire the AC line to L1 and L2 terminals, as shown in Figure 4.

B. Permanent Magnet (PM) Motor Connection – Wire the motor armature leads to A+ and A- terminals, as shown in Figure 4. On dual voltage models, be sure that Jumper J1 is set to the corresponding motor voltage. Be sure that the correct Plug-In Horsepower Resistor® is installed (see Table 3, on page 12). **Note:** If the motor runs in the opposite direction than is desired, disconnect power and reverse the motor leads.

C. Main Speed Potentiometer

Connection – The control is supplied with a Main Speed Potentiometer. Connect the Main Speed Potentiometer high side to P3 terminal, wiper to P2 terminal and low side to P1 terminal, as shown in Figure 5. Rotating the Main Speed Potentiometer clockwise will increase motor speed. Rotating the Main Speed Potentiometer counterclockwise will decrease motor speed.

D. Voltage Following Connection – A 0 - 5 Volt DC analog signal voltage can also be used to control motor speed. See Figure 6, on page 14. Connect the

FIGURE 4 – POWER CONNECTIONS






FIGURE 5 – MAIN SPEED POTENTIOMETER CONNECTION



analog signal voltage to P2 (signal) and P1 (-) terminals. Adjustment of the MIN trimpot may be necessary to achieve a 0 Volt DC output with a 0 Volt DC input.


Note: The input signal can be non-isolated or earth grounded since the KBWS has built-in signal isolation.

FIGURE 6 – VOLTAGE FOLLOWING CONNECTION




- E. Inhibit Circuit Connection** – The control is supplied with an inhibit connector (CON1). See Figure 7. This circuit is used to electronically stop the control. When the Inhibit Switch is closed, the control will coast-to-stop. When the Inhibit Switch is opened, the control will accelerate to the Main Speed Potentiometer setting.

FIGURE 7 – INHIBIT CONNECTION



- F. Enable Circuit Connection** – The control can also be started and stopped with an Enable Circuit (close to start). See Figure 8. The Enable function is established by wiring a switch in series with the high side of the Main Speed Potentiometer lead which connects to the P3 terminal. When the Enable switch is closed, the control will accelerate to the Main Speed

FIGURE 8 – ENABLE CIRCUIT CONNECTION



Potentiometer setting. When the Enable Switch is opened, the control will coast to the minimum speed setting.





Warning! Do not use Enable as a safety disconnect. Use only the AC line for this purpose.

IV. SETTING SELECTABLE JUMPER (ON DUAL VOLTAGE MODELS)

All dual voltage KBWS models contain a selectable jumper which must be set before the control can be used. See Figure 1, on page 8, for the location of Jumper J1.

Motor Voltage Selection (J1): Jumper J1 is factory set to the “180V” position for 180 Volt motors. For 90 or 130 Volt motors, set Jumper J1 to the “90V” position. See Figure 9.

FIGURE 9 – MOTOR VOLTAGE SELECTION

J1 Set for 180 Volt Motor (Factory Setting)	J1 Set for 90 Volt Motor
80V 90V  J1	180V 90V  J1

V. MOUNTING INSTRUCTIONS

It is recommended that the control be mounted on a flat surface with adequate ventilation. If the control is mounted in a closed, unventilated location, a minimum of a 12" x 12" x 12" enclosure should be used to allow for proper heat dissipation. The maximum allowable ambient temperature at full rating is 45 °C (113 °F).

Care should be taken to avoid extreme hazardous locations where physical damage can occur or where the control will be exposed to contaminants such as water, metal chips, solvents or excessive vibration. Leave enough room around the control to allow for AC line, motor connections and any other wiring. See Figures 2A and 2B, on pages 9 and 10.

VI. RECOMMENDED HIGH VOLTAGE DIELECTRIC WITHSTAND TESTING (Hi-Pot Testing)

Note: This control has been Hi-Pot tested at 1500 Volts AC.

Testing agencies such as UL, CSA, VDE, etc., usually require that equipment undergo a hi-pot test. In order to prevent catastrophic damage to the speed control, which has been installed in the equipment, it is recommended that the following procedure be followed. Figure 10, on page 17 shows a typical hi-pot test setup.

Note: All equipment AC line inputs must be disconnected from the AC power.

- A. Connect all equipment AC power input lines together and connect them to the H. V. lead of the hi-pot tester. Connect the RETURN lead of the hi-pot tester to the frame on which the control and other auxiliary equipment are mounted.
- B. The hi-pot tester must have an automatic ramp-up to the test voltage and an automatic ramp-down to zero voltage.


Note: If the hi-pot tester does not have automatic ramping, then the hi-pot output must be manually increased to the test voltage and then manually reduced to zero. This procedure must be followed for each machine tested. A suggested hi-pot tester is Slaughter Model 2550.



WARNING! Instantaneously applying the hi-pot voltage will cause irreversible damage to the speed control.

- C. The hi-pot test voltage should be set in accordance to the testing agency standards and the leakage current should be set as low as possible without causing nuisance trips.
- D. To eliminate motor speed control damage due to auxiliary equipment hi-pot failure, it is also recommended that all signal inputs be wired together and connected to the AC input lines as shown.

FIGURE 10 – HI-POT TEST SETUP



VII. OPERATION.

(You must read the Safety Warning on page 5 before proceeding).

After the KBWS has been properly setup, the startup procedure can begin. If AC power has been properly brought to the control, the PWR ON LED will illuminate green. Before starting, be sure that the Main Speed Potentiometer is set to the zero speed position. The motor should begin to run as the Main Speed Potentiometer is rotated clockwise.

Note: If the motor runs in the incorrect direction, it will be necessary to disconnect the AC line, reverse the motor leads and repeat the startup procedure.

Application Note: This control is not recommended for applications where the AC line is to be rapidly cycled on and off.

VIII.AC LINE FUSING

The KBWS does not contain AC line fuses. Most electrical codes require that each ungrounded conductor contain circuit protection. It is recommended to install a fuse (Littelfuse 326, BUSS ABC or equivalent) or a circuit breaker in series with each ungrounded conductor. An AC Line Fuse Kit (P/N 9851) is available. Check all electrical codes that apply to the application. See Table 4.

**TABLE 4 – RECOMMENDED
AC LINE FUSE**

Model	Recommended AC Line Fuse (Amps RMS)
KBWS-12	5
KBWS-15	10
KBWS-22D	5
KBWS-25D	10

IX. TRIMPOT ADJUSTMENTS

The KBWS contains trimpots which are factory set for most applications. Figure 1, on page 8 illustrates the location of the trimpots and their approximate calibrated positions. Some applications may require readjustment of the trimpots in order to tailor the control for a specific requirement. Readjust trimpots as described below.



Warning! If possible, do not adjust trimpots with main power applied. If adjustments are made with main power applied, an insulated adjustment tool must be used and safety glasses must be worn. High voltage exists in this control. Fire and/or electrocution can result if caution is not exercised. Safety Warning, on page 5, must be read and understood before proceeding.

- A. Maximum Speed (MAX)** – Sets the maximum speed of the motor. The MAX trimpot is factory set for 100% of base motor speed. For a higher maximum speed setting, rotate the MAX trimpot clockwise. For a lower maximum speed setting, rotate the MAX trimpot counterclockwise. See Figure 11.

To Calibrate the MAX Trimpot:

1. Adjust the MAX trimpot to the desired position and set the Main Speed Potentiometer for full output voltage.
2. Monitor the armature voltage and readjust the MAX trimpot to the desired voltage.

- B. Minimum Speed (MIN)** – Sets the minimum speed of the motor. The MIN trimpot is factory set for 0% of base motor speed. For a higher minimum speed setting, rotate the MIN trimpot clockwise. See Figure 12.

FIGURE 11 – MAX TRIMPOT RANGE





FIGURE 12 – MIN TRIMPOT RANGE



To Calibrate the MIN Trimpot:

1. Adjust the MIN trimpot to the desired position and set the Main Speed Potentiometer fully counterclockwise.
2. Monitor the armature voltage and readjust the MIN trimpot to the desired voltage.

C. Acceleration (ACC) – Sets the amount of time it takes for the control voltage to reach full output. The ACC trimpot is factory set to 1 second. To increase the acceleration time, rotate the ACC trimpot clockwise. To decrease the acceleration time, rotate the ACC trimpot counterclockwise. See Figure 13.

D. Deceleration (DEC) – Sets the amount of time it takes for the control voltage to reach zero. The DEC trimpot is factory set to 1 second. To increase the deceleration time, rotate the DEC trimpot clockwise. To decrease the deceleration time, rotate the DEC trimpot counterclockwise. See Figure 14.

E. Current Limit (CL) – Sets the current limit (overload), which limits the maximum current to the motor. The CL trimpot is factory set to 150% of the nominal motor current established by the Plug-In Horsepower Resistor®. See Table 3, on page 12. To increase the current limit, rotate the CL trimpot clockwise. To decrease the current limit, rotate the CL trimpot counterclockwise. See Figure 15.

FIGURE 13 – ACC TRIMPOT RANGE




FIGURE 14 – DEC TRIMPOT RANGE





FIGURE 15 – CL TRIMPOT RANGE



CAUTION! Adjusting the CL above 150% of motor rating can cause overheating and demagnetization of some PM motors. Consult the motor manufacturer. Do not leave the motor in a locked condition for more than a few seconds since armature damage may occur.


To Calibrate the CL Trimpot:

1. Disconnect the AC power. Wire in a DC ammeter in series with either motor armature lead. Lock motor shaft. Be sure that the correct Plug-In Horsepower Resistor® is installed.
2. Set the CL trimpot fully counterclockwise.
3. Apply power. Adjust the CL trimpot until the desired current limit (CL) setting is reached.

WARNING! Do not leave the motor shaft locked for more than 2 - 3 seconds or motor damage may result.

F. IR Compensation (IR) – Sets the amount of compensating voltage required to keep the motor speed constant under changing loads. The IR trimpot is factory set for 10 Volts (at 180/220 Volts DC output) and 5 Volts (at 90/130 Volts DC output). For higher compensating voltage, rotate the IR trimpot clockwise. For lower compensating voltage, rotate the IR trimpot counterclockwise. See Figure 16. Be sure the proper Plug-In Horsepower Resistor® is installed. See Table 3, on page 12.

FIGURE 16 – IR TRIMPOT RANGE



Note: If the IR compensation is set too high, unstable (oscillatory) operation will result.

To Calibrate the IR Trimpot:

1. Run the motor at approximately 30 - 50% of rated speed at no load and measure the actual speed.
2. Load the motor to the rated current. Adjust the IR trimpot so that the loaded speed is the same as the unloaded speed measured in the previous step.

X. DIAGNOSTIC LEDs

The KBWS is designed with PC board mounted LEDs to display the control's operational status.

A. Power On (PWR ON) – The PWR ON LED will illuminate green when the AC line is applied to the control.

B. Overload (CL) – The CL LED will illuminate red when the control goes into current limit, indicating that the current limit set point has been reached (established by the CL trimpot setting and the selection of the Plug-In Horsepower Resistor®).

If the CL LED remains illuminated during normal control operation, a fault condition may exist. Possible causes for this condition are as follows.

1. Motor is overloaded. Check motor current.
2. Motor may be defective. Check motor for shorts or grounds.
3. CL may be set too low. Check setting of CL trimpot.

Note: In some applications, especially those requiring the motor to cycle on and off or from one speed to another or from stop to high speed, the CL LED may blink, indicating a transient overload. This may be a normal condition for the application.

4. Proper Plug-In Horsepower Resistor® is not installed. See Table 3, on page 12.

XI. OPTIONAL ACCESSORIES

Complete instructions and connection diagrams are supplied with all accessories to facilitate installation.

- A. DIN Rail Mounting Kit (P/N 9995)** – Allows mounting of the control to a DIN rail.
- B. Product Safety Module (PSM) (P/N 8611)** – Protects the machine operator from injury due to a runaway or uncontrolled acceleration condition.
- C. AC Line Fuse Kit (P/N 9851)**

XII. LIMITED WARRANTY

For a period of 18 months from the date of original purchase, KB Electronics, Inc. will repair or replace, without charge, devices which our examination proves to be defective in material or workmanship. This warranty is valid if the unit has not been tampered with by unauthorized persons, misused, abused, or improperly installed and has been used in accordance with the instructions and/or ratings supplied. The foregoing is in lieu of any other warranty or guarantee, expressed or implied. KB Electronics, Inc. is not responsible for any expense, including installation and removal, inconvenience, or consequential damage, including injury to any person, caused by items of our manufacture or sale. Some states do not allow certain exclusions or limitations found in this warranty and therefore they may not apply to you. In any event, the total liability of KB Electronics, Inc., under any circumstance, shall not exceed the full purchase price of this product. (rev 2/2000)



WARNING! You must read Safety Warning on page 5 before installing and operating this control.



KB Electronics, Inc.

12095 NW 39th Street, Coral Springs, FL 33065-2516 • (954) 346-4900 • Fax (954) 346-3377
Outside Florida Call TOLL FREE (800) 221-6570 • E-mail – info@kbelectronics.com
www.kbelectronics.com