ADJUSTABLE FREQUENCY DRIVES **FOR 3-PHASE AC MOTORS** NEMA-4X/IP-65

Washdown and Watertight for Indoor and Outdoor use

Models KBAC-24D, 27D, 29, 45, 48

Rated for 208-230 and 400/460 Volt 50 & 60 Hz 3-Phase AC Induction Motors from Subfractional thru 5 HP Operates from 115, 208/230, and 400/460 Volt 50/60 Hz AC Line

TYPICAL APPLICATIONS



- · Conveyors · Feeders · HVAC · Pumps
- Portable Equipment used with GFCIs







STANDARD FEATURES

- Industrial Duty Die-Cast Aluminum Case with Hinged Coventvailable in dark gray finish or FDA pproved white finish.
- Simple to OperateDoes not require programmildsges trimpots and jumpers/hich are factory set for most applications.
- Motor HP Selection JumperAllows the drive to be used on a wide range of motor horsepower without recalibration.
- Diagnostic LEDs:Power on (POWER) and drive status (STATUS).
- Run/Fault Relay Output ContactsCan be used to turn on or off equipment or to signal a warning if the drive is put into the Stop Mode or a fault has occurred.
- Start/Stop Switch:Provides electronic start and stop functions.
- Barrier Terminal Block: Facilitates wiring of motor, AC line, and Run/Fault Relay Output
- Jumper Selection of Drive Output Frequencyncreases the motor speed up to two times the ræd RPM.
- · Ride-Through: Provides smooth recovery to the previous set speed during a momentary power loss (of less than 2 seconds).
- Holding Torque at Zero SpeedResists motor shaft rotation when the drive is in Stop Mode.
- · GFCI Operation!

PERFORMANCE FEATURES

- Power Start™: Provides more than 200% starting torque which ensures startup of high frictional loads.
- Slip Compensation with Static Auto-Tune and BoosProvides excellent load regulation over a wide speed range.
- · Speed Range: 60:1

PROTECTION FEATURES

- Motor Overload (ft) with RMS Current Limit:Provides motor overload protection which prevents motor burnout and eliterimuisance trip3.
- Electronic Inrush Current Limit (EICL™): Eliminates harmful inrush AC line current
- Short Circuit: Shuts down the drive if a short circuit occuthe motor (phase-to-
- Regeneration: Eliminates tripping due to high bus voltage caused by rapid deceleration of high inertial loads.
- Undervoltage and Overoltage Shuts down the drive if the AC line input golgaes above or below the operating range.
- MOV Input Transient Suppression.
- · Microcontroller Self Monitoring and Auto-Reboot.

TRIMPOT ADJUSTMENTS

- Minimum Speed(MIN)
- Maximum Speed(MAX)
- Acceleration (ACC) • Slip Compensation(COMP) • Current Limit (CL)
- · Deceleration (DECEL) • Boost (BOOST)
- · Jog (JOG)

DESCRIPTION

The KBAC Adjustable Frequency Drives are variable speed controls housed in a rugged NEMA-4X / IP-65 washdown and watertight die-cast aluminum enclosure. They are designed to operate 208 – 230 and 400/460 Volt 50 & 60 Hz 3-phase AC induction motors from subfractional thru 5 HP. The sine wave coded Pulse Width Modulated (PWM) output operates at a carrier frequency of 16 kHz, which provides high motor efficieng and low noise. Adjustable Linearceleration and Deceleration make the drive suitable for soft-starpplications.

Due to its user-friendly design, the KBAC is easy to install and operate. Tailoring to specific applications is accomplished with selectable jumpers and trimpots, which eliminate the computer-like programming required on other drives. However, for most applications no adjustments are necessary. For more advanced programming, PC based Drive-Link™ software is available.

Main features include adjustable RMS Current Limit²aMbtor Overload Protection. In addition, Adjustable Slip Compensation with Static Auto-Tune and Boost provides high torque and excellent load regulation over a wide speed range. Power Start[™] delivers over 200% motor torque to ensure startup of high frictional loads. Electronic Inrush Current Limit (EICL™) eliminates harmful AC line inrush current. A Run/Fault Relay is provided, which can be used to turn on or off equipment or to signal a warning if the drive is put into the Stop Mode or if a fault has occurred. The drive is suitable for machine or variable torque (HVAQI) cations. Also, a jumper is provided for selection of Regenerative or DC Injection Braking.

Standard front panel features include diagnostic LEDs for "Power On" and "Drive Status", a Start/Stop Switch, and a Main Speed Potentiometer. Other features include a Barrier Erminal Block to facilitate wiring of the AC line and motor, adjustable trimpots (MIN, MAX, ACCEL, DECEL, CO, MOP., JOG, BOOST), customer selectable jumpers (Line Voltage (dual voltage models only), Motor Horsepower, Automatic Ride-Through / Manual Start, Motor Frequency, Frequency Multiplier, Fixed/Adjustable Boost, Regenerative/Injection Braking, "Run" or "Fault" Output Relay Operation, NO/NC \$top Contact, Constant/Variable Torque Verload Selection).

Optional accessories include: Forward-Stop-Reverse Switch, On/Off AC Line Switch, Run-Stop-Jog Switch, Signal Isolator, Auto/Manual Switch, Class "A" AC Line Filter, Multi-Speed Board, Programming Kit, Modbus Communication Module, and Liquidtight Fittings. A connector is provided for easy installation of accessories.

Custom software: All models can be factorogrammed forpaplications which require special timing, PLC functions, and GFCI operation – Contact our Sales Department.

* Requires CE approved RFIiRer See AC Line Atters, in Optional Accessories.

Notes: 1. Requires optional softwate.UL approved as an electronic overload protector for motors. 3. When the drive is set for DC Injection Braking, DECELTrimpot is used to adjust the braking intensity



TABLE 1 - GENERAL PERFORMANCE SPECIFICATIONS

Description	Specification	Factory Setting		
115 Volt AC Line Input Voltage Operating Range (Volts AC)	115 (±15%)	_		
208/230 Volt AC Line Input Voltage Operating Range (Volts AC)	208 (–15%) / 230 (+15%)	_		
400/460 Volt AC Line Input Voltage Operating Range (Volts AC)	380 (-15%) - 460 (+15%)	_		
Maximum Load (% Current Overload for 2 Minutes)	150	_		
Carrier, Switching Frequency (kHz)	16, 8	_		
Signal Following Input Voltage Range ¹ (Volts DC)	0 – 5	_		
Output Frequency Resolution (Bits, Hz)	10, .06	_		
Minimum Speed Trimpot (MIN) Range (% Frequency Setting)	0 – 40	0		
Maximum Speed Trimpot (MAX) Range (% Frequency Setting)	70 – 110	100		
Acceleration Trimpot (ACCEL) and Deceleration Trimpot (DECEL) Range (Seconds)	.3 – 20	1.5		
Boost Trimpot (BOOST) Range (Volts/Hz)	0 – 30	5		
Slip Compensation Trimpot (COMP) Range at Drive Rating (Volts/Hz)	0 – 3	1.5		
Current Limit Trimpot (CL) Range (% Full Load)	40 – 200	160		
Jog Trimpot (JOG) Range (% Frequency Setting)	0 – 100	35		
Motor Frequency Setting (Hz) (Jumper J5)	50, 60	60		
Output Frequency Multiplier (1X, 2X) (Jumper J4) ²	1, 2	1		
Minimum Operating Frequency at Motor (Hz)	1	_		
Speed Range (Ratio)	60:1	_		
Speed Regulation (30:1 Speed Range, 0 - Full Load) (% Base Speed) ³	2.5	_		
Overload Protector Trip Time for Stalled Motor (Seconds)	6	_		
Undervoltage/Overvoltage Trip Points for 115 Volt AC Line Input (±5%) (Volts AC) ⁴	76 – 141	_		
Undervoltage/Overvoltage Trip Points for 208/230 Volt AC Line Input (±5%) (Volts AC) ⁴	151 – 282	_		
Undervoltage/Overvoltage Trip Points for 400/460 Volt AC Line Input (±5%) (Volts AC) ⁴	302 – 567	_		
Run/Fault Relay Output Contact Rating (Amps at 30 Volts DC, 125 Volts AC, 250 Volts AC)	1, 0.5, 0.25	_		
Operating Temperature Range (°C / °F)	0 - 45 / 32 - 113	_		

Notes: 1. Requires an isolated signal. If a non-isolated signal is used, or if using 0 to ± 2.5 thru 0 to ± 2.5 t

TABLE 2 – ELECTRICAL RATINGS


			AC Line Input				Drive Output												
	Part No.				Maximum	Fuse or Circuit	Voltage Range	Maximum Continuous			Motor Horsepower					Wt.			
Model No.	Gray	White ¹	Volts AC (50/60 Hz)	Phase (\phi)	Current (Amps AC)	Breaker Rating (Amps)	(Nominal) (Volts AC)	Load Current (RMS Amps/Phase)	Horsepower (HP (kW))		Selection ² (Jumper J2)				lbs	kg			
KBAC-24D 9987	0097	9988 -	7 9988	115	1	16	20	0 – 230	3.6	1 (.75)	1	3/4	1/2	1/4	1/8	5.9	2.7		
	3307		208/230	1	10	15	0 – 230	3.0	1 (.73)		3/4	1/2	1/4	1/0	3.5	2.1			
KBAC-27D	KBAC-27D 9520 95	9521	115	1	22	25	0 – 230	5.5	1½ (1.13)	_	1½4	1	3/4	1/2	10.3	4.7			
KBAC-27D 9320	9320	3321	208/230	1	15	20	0 – 230	6.7	2 (1.5)	24	1/2	ľ	3/4	1/2	10.3	4.7			
							A B C D			n	Е								
										A	D	· ·	ע						
KBAC-29 952	0528	9528	528 9529	0520	9529	208/230	1	15	20	0 – 230	6.7	2 (1.5)	_	2 ⁵	1½	1	3/4	10.3	4.7
	3020	3323		200/200	3	10.8	15	0 – 230	9.0	3 (2.25)	3 ⁵		1/2		0/4	10.5	7.7		
KBAC-45 ³	9530	9531	400/600	3	5.3	10	0 - 400/460	4.6	3 (2.25)	3	2	1½	1	3/4	10.3	4.7			
KBAC-48 ³	9540	9541	400/600	3	9.6	10	0 - 400/460	8.3	5 (3.75)	5	3	2	1½	1	10.3	4.7			

Notes: 1. White FDA approved finish. 2. Bold indicates factory setting. Jumper J2 on Model KBAC-24D is labeled "1", "3/4", "1/2", "1/4", "1/8" (factory set to the "1" position). Jumper J2 on Models KBAC-27D is labeled "2", "1", "3/4", "1/2" (factory set according to the table). 3. Models KBAC-45, 48 are rated 0 – 400 Volts AC for 50 Hz motor operation and 0 – 460 Volts AC for 60 Hz motor operation. 4. Model KBAC-27D is rated 1½ HP maximum with 115 Volt AC line input and 2 HP maximum with 208/230 Volt AC line input. 5. Model KBAC-29 is rated 2 HP maximum with single-phase AC line input and 3 HP maximum with 3-phase AC line input.




FIGURE 1 - MODEL KBAC-24D MECHANICAL SPECIFICATIONS (Inches/mm)

FIGURE 2 – MODELS KBAC-27D, 29, 45, 48 MECHANICAL SPECIFICATIONS (Inches/mm)



Contains 3 mounting holes for standard 1/2" liquidtight fittings


* Tighten these screws, in the sequence shown, to 12 in-lbs (14 kg-cm).



Contains 2 mounting holes for standard 1/2" liquidtight fittings and 1 mounting hole for standard 3/4" liquidtight fitting.

* Tighten these screws, in the sequence shown, to 12 in-lbs (14 kg-cm).

FIGURE 3 - CONTROL LAYOUT 1




Notes: 1. Layout of Model KBAC-24D varies slightly. 2. On Model KBAC-24D, the JOG and COMP Trimpots are located vertically, along the right edge of the PC board (below the mounting screw). 3. On Model KBAC-24D, Jumper J2 is labeled "1", "3/4", "11/2", "1/4", "11/4", "11/8" (factory set to the "1" position). On Model KBAC-27D, Jumper J2 is labeled "2", "11/2", "11/4", "11/2" (factory set to the "1" position). On Models KBAC-29, 45, 48, Jumper J2 is labeled "A", "B", "C", "D", "E" (factory set according to Table 2, on page 2.) 4. On Model KBAC-24D, Jumper J3 is labeled "AUTO" and "MAN".



FIGURE 4 - MODELS KBAC-24D, 27D MOTOR & AC LINE INPUT CONNECTIONS

TB1 MOTOR V W L1 L2 Chassis Ground (Earth) Motor TB1 AC LINE Chassis Ground (Earth) AC LINE Chassis

FIGURE 5 - MODELS KBAC-24D*, 27D AC LINE INPUT VOLTAGE SELECTION



^{*} Layout of Model KBAC-24D varies slightly.

FIGURE 6 - MODELS KBAC-29, 45, 48 MOTOR & AC LINE INPUT CONNECTIONS




TABLE 3 – OPTIONAL ACCESSORIES

Description		Model KBAC-24D	Model KBAC-27D	Model KBAC-29	Model KBAC-45	Model KBAC-48
Forward-Stop-Reverse Switch – Provides motor reversing and stop functions. Mounts on the enclosure and is supplied with a switch seal to maintain liquidtight integrity.	9480	9480	9480	9480	9480	
On/Off AC Line Switch – Disconnects the AC line. Mounts on the enclosure cover and is supplied with a maintain liquidtight integrity.	9482	9523	9532			
Run-Stop-Jog Switch – Selects speed setting from either the Main Speed Potentiometer or the JOG Triu the enclosure cover and is supplied with a switch seal to maintain liquiditight integrity.	9340	9340 9340 9340			9340	
Signal Isolator – Provides isolation between a non-isolated signal source and the drive. Mounts on the with four snap-ins.	9600*	9600*	9600*	9600*	9600*	
Auto/Manual Switch – When used with the Signal Isolator, it selects remote process signal or the Main Potentiometer. Mounts on the enclosure cover and is supplied with a switch seal to maintain liquidtight in	9481	9481	9481	9481	9481	
AC Line Filter 1 – Provides Class A RFI (EMI) suppression. Installs onto the drive's PC board with quick-connect terminals.	Suffix "S"	9507	9512	9479	9479	9479
Suffix "S": Filter is used when On/Off AC Line Switch is installed. Suffix "NS": Filter is used when On/Off AC Line Switch is not installed.	Suffix "NS"	9507	9512	9515	9515	9515
Multi-Speed Board – Provides multi-speed operation using external contacts or a PLC. Mounts on the dwith four snap-ins.	9489	9489	9489	-	_	
Programming Kit ² – Includes DownLoad Module™ (DLM) handheld programming device which upload drive programs, PC to DLM serial communication cable, DLM to drive communication cable, and PC Wind Drive-Link™ communication software.	9582	9582	9582	9582	9582	
Modbus Communication Module – Allows direct communication between drive and Modbus ³ protocol.	9517	9517	9517	9517	9517	
Liquidtight Fittings – Provide a liquidtight seal for wiring the drive. Kit includes three 1/2" and one 3/4"	9526	9526	9526	9526	9526	

Notes: 1. Complies with CE Council Directive 89/336/EEC Industrial Standard. 2. If a USB communication cable is required, purchase Part No. 19008. 3. Other protocols available – contact our Sales Department.



* Warning! It is highly recommended that the Signal Isolator (Part No. 9600) be installed when using the drive with external control signals.

