HE2B Series Redundant (Double) Basic Enabling Switch

HE2B Key features include:

- 3 position funtionality (OFF ON –OFF) as required for manual robotic (
- Ideally suited for use as enabling (aka "deadman") switch on teach pene
- Provides a high level of safety based on human behavioral studies that personnel may squeeze OR let go when presented with a panic situatio
- Snap acting contacts from DO (1 2)
- Positive action contacts from 000ff (2) 3) ensure no contact welding (pe EN60947-5-1 / IEC60947-5-1)
- Contacts will not re-close when released from Off(1 1) (per IEC60204-1 9.2.5.8)
- Multiple contacts for enhanced reliability
- · Monitoring contacts in addition to main load contacts
- Available with or without rubber cover (cover provides IP65 watertight seal)



Specifications

-peeniee				
Conforming to Standards		IEC60947-5-1, EN60947-5-1, JIS C8201-5-1, UL508, CSA C22.2 No 14 Ordering Information		
Application	Standards	ISO12100/EN292, IEC60204-1/EN60204-1, ISO11161/prEN11161, ISO1 EN775, ANSI/RIA R15.06	⁰²¹ ÅE2B - M <u>2 Q Q P Y</u>	
Operating Temperature		–25 to +60°C (no freezing)		
Operating Humidity		45 to 85% RH (no condensation)	3 Position Rubber Cover	
Storage Temperature		-40 to +80°C (no freezing)	Switch Color 2: 2 contacts None: without	
Pollution Degree		2 (inside of panel/contact side)	(DPDT) cover	
		3 (outside of panel/operating side)	Y: Yellow B: Black	
Contact Resi	istance	50mΩ maximum	D. Diack	
Insulation Re	asistanco	Between live and dead metal parts: $100M\Omega$ maximum	Rubber Cover	
Insulation Re	esistance	Between positive and negative live parts: $100 \text{M}\Omega$ minimum	None: without cover	
Impulse Wit	hstand Voltage	2.5kV	P: with cover	
Operating F	requency	1200 operations/hour	Push Monitor	
Mechanical Life		Position 2 2: 1,000,000 operations minimum Position 2 2 3 1: 100,000 operations minimum	Return Monitor Switch Switch 0: None	
Electrical Life	e	100,000 (at full rated load)	0: None 1: 1 contact 1: 1 contact 2: 2 contacts	
Shock	Operating Extremes	100m/š(10 G)	2: 2 contacts	
Resistance	Damage Limits	1000m/\$(100 G)		
Vibration	Operating Extremes	5 to 55Hz, amplitude 0.5mm minimum		
Resistance	Damage Limits	16.7Hz, amplitude 1.5mm minimum		
Terminal		0.110" quick connect / solder terminal		
Recommend	d Wire Size	0.5mm maximum / 1 line (20AWG)		
Solder Heat	Resistance	260°C / 3 seconds maximum		
Terminal Pulling Strength		20N minimum		
Recommended Screw Torque		0.5 to 0.8Nm		
Degree of Protection		with rubber cover: IP65, without rubber cover: IP40 (IEC 60529),		
Conditional Short-Circuit Current		50A (250V)		
Recommended Short Circuit Protection		250V/10A fast blow fuse (IEC 60127-1)		
Weight		Approx. 26g (without cover), 30g (with cover)		
Circuit Opening Force		60N minimum (button return monitor & button push monitor)		
Actuating Force (Operating)		500N minimum		



HE2B Series

IDEC

IDEC

HE2B Series

Enabling Switches

Part Numbers

Model				Part Number		
			3 Position Switch	Push Monitor Switch	Return Monitor Switch	Part Number
	Without Rubber Cover		2	0	0	HE2B-M200
A			2	1	1	HE2B-M211
- Electronic de la construcción de la const			2	2	2	HE2B-M222
	With Rubber Cover	Yellow	2	0	0	HE2B-M200PY
			2	1	1	HE2B-M211PY
			2	2	2	HE2B-M222PY
		Black	2	0	0	HE2B-M200PB
000.			2	1	1	HE2B-M211PB
			2	2	2	HE2B-M222PB

Overview


Ratings

Contact Ratings	5						
Rated Insulation Volute (Ui)				250V			
Thermal Current (Ith)				ЗA			
Rated Operating Voltage (Ue)					30V	125V	250V
	3 Position Switch	AC	Resistive Load (AC-12)	-	1A	0.5A	
			Inductive Load (AC-15)	-	0.7A	0.5A	
		witch	DC	Resistive Load (DC-12)	1A	0.2A	-
Rated Operating			DC	Inductive Load (DC-13)	0.7A	0.1A	-
Current (le)	Push/return Monitor Switch (NC Contacts)		AC	Resistive Load (AC-12)	-	2A	1A
		AC	Inductive Load (AC-15)	-	1A	0.5A	
		DC	Resistive Load (DC-12)	2A	0.4A	0.2A	
			Inductive Load (DC-13)	1A	0.22A	0.1A	
		3 Position Switch		2 contacts (DPDT)			
Contact Structure		Button Return Monitor Switch			0 to 2 contacts		

Button Push Monitor Switch

Minimum applicable load (reference) = AC/DC3V • 5mA (for reference only)










0 to 2 contacts








HE2B Series


Operating Characteristics

Operating Characteristics (without rubber cover/center of button being pushed)




Using rubber cover will change the operating load because the operating temperature would increase


Dimensions (mm) Without Rubber Cover



With Rubber Cover



Mounting Hole Layout



Accessories Replacement Rubber Cover

Apperance	Color	Part Number	Material	
	Yellow	HE9Z-D2Y	Silicon Rubber	
	Black	HE9Z-D2B	Shicon Rubbel	

IDEC

Use proper wire diameter to meet voltage and current requirements. Using

If the panel is not level when mounting an enabling switch, the waterproof

 The rubber boot has a tab to be used for orientation. When making a positioning hole in a panel, do not make a hole in the rubber boot, or the waterproof feature cannot be guaranteed. When the positioning hole is not on the panel,

When tightening the locking ring, secure the flange to prevent the enabling

switch from rotating. In applications where the enabling switch is to be

remove the tab, but do not make a hole in the rubber boot.

rotated, mount the switch in a recess on the panel as shown.

Positioning

Projection

Anti-rotation Ring

Locking Ring

improper wires or incomplete soldering may cause fire due to abnormal heat



generation.

HE3B

feature cannot be guaranteed.

Mounting Panel

Recommended Torque

100000

ιлл

cove

base


base

Safety Precautions

- In order to avoid electric shock or fire, turn power off before installation, removal, wire connection, maintenance or inspection of switch.
- Follow specification when installing. Improper electrical load may damage switch, cause electric shock, or fire.

Installation Precautions HE2B

• M3 nut is inside the rubber cover.



HE2B/HE3B

• A change in internal air pressure may cause the rubber boot to expand and shrink on an enabling switch that has the rubber boot sealed. This may affect the performance of the switch. Periodically check to ensure that the enabling switch is operating correctly.

Wiring Precautions HE1B/HE2B/HE3B

- Applicable wire size is 0.5mm² (20AWG) (maximum) / 1 line.
- When soldering the terminal, solder at a temperature of 260°C within 3 seconds. Use non-corrosive liquid rosin as soldering flux.

HE1G

• Wire Stripping Information

Wire Length	Terminal Number 1-4	Terminal Number 5-8					
L1, L2 (mm)	L1=40mm	L2=27mm					
L3 (mm)	L3=6mm						
$L_{3} + L_{1} + Cable Gland$ $I_{3} + L_{2} + Dase$ $I_{3} + L_{2} + Base$ $I_{3} + L_{2} + Base$							

 See Drawing Above
 Recommended Torque

 Rubber Boot & Base
 A
 1.2±0.1Nm

 Connector & Grip Switch
 B
 4.0±0.3Nm

 Connector
 C
 4.0±0.3Nm

 Terminal Screw
 D
 0.5±0.6Nm

Е

ENNANA

base

A (M4 screw x 3)

IDEC

• Applicable Wire Size:0.14 to 1.5mm² (24 - 16AWG, one wire per terminal)

Use Precautions HE2B/HE3B/HE1G

Terminal No

 To ensure the highest level of reliability connect both contacts to a monitoring device such as a safety relay.

HE1B/HE2B/HE3B

Do Not Remove

• When installing the enabling switch ensure that it cannot be accidently activated. For example, a protrusion from a teaching pendant could cause the enabling switch to be activated by the weight of the teaching pendant.